



Installation Instructions

For Torchier Lamp
ITEM#30690

WARNING

- *Risk of shock, do not plug the unit before assembly.
- *Do not exceed the maximum wattage rating.(Max.150W)NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE
- *Before you light the torchier lamp, please follow the instructions step by step.
- *Lamps must total no more than 190 watts –Torchiere is Non-Compliant if it is able to draw more than 190 Watts.

INSTALLATION

- 1.Thread Bottom Tube(B) clockwise onto Base(A) until tight.
- 2.Thread Ploy (C) clockwise onto Bottom Tube(B) until tight.
- 3.Thread Top Tube(D) clockwise onto the Poly(C) until tight.
- 4.Thread Poly(E) clockwise onto the Top Tube(D) until tight.
- 5.Put Glass Shade(F) on Poly(E),then tighten Lamp Outer(G) clockwise to secure the Shade(F).
- 6.Adjust the Shade until it is leveled horizontally.
- 7.Install a (Type A) Light Bulb in the Lamp Holder.

IMPORTANT SAFETY INSTRUCTIONS

- 1.This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not change or alter the plug.

IN AN ONGOING EFFORT TO BE ENVIRONMENTALLY FRIENDLY AND IN COMPLIANCE WITH CALIFORNIA TITLE 20 AN ENERGY SAVING COMPACT FLUORESCENT BULB(S) IS INCLUDED. PLEASE NOTE THAT THE LIFE EXPECTANCY OF THE BULB(S) IS NOT GUARANTEED.

USER INSTRUCTION FOR 190W-LIMITED WATTAGE USE (WITH SWITCH UNIT)

This torchier luminaire has been provided with a “190-watt Limited Wattage Unit” that is located on the cord. This limited wattage unit meets a Federal Regulation from Energy Policy Act of 2005. The bulb used in a torchier luminaire can not be more than 190 watts. When the bulb exceeds 190 watts the limited wattage unit will shut down the power to the luminaire. If this has happened you must: 1. Turn off the switch on the unit. 2. Lower the total wattage to be less than 190 watts. 3. Turn on the switch on the unit. This will restart the limited wattage unit. The luminaire will work again properly.

