

INSTALLATION INSTRUCTIONS FOR 728-355

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.

ASSEMBLY THE FIXTURE

ASSEMBLY THE FIXTURE (Fig.1)

1. Carefully remove the fixture from the carton and check that all parts are included as shown in the illustration.
2. Shut off power at the circuit breaker and remove old fixture including the crossbar.
3. Slide fixture loop (1) onto nipple(2) the top of fixture body.
4. Spread the 3 arms (5) and the 3 arms (6) until they are 60 degrees apart (see sketch 2 below).
5. Spread the 6 arms (4) until they are 60 degrees apart (see sketch 1 below).
6. Fix the arm(4) onto the top of distributor by the ball knob stud (3).
7. Fix the endmost arm (12) onto the pin (10) using the screws (11).
8. Slide glass shade (8) over socket (9), then secure it using socket ring(7).

HANGING THE FIXTURE (Fig.3)

1. Shut off the power at the circuit breaker and remove old fixture from the ceiling, including the old cross bar.
2. Carefully unpack the new fixture and lay all the parts on a clear surface.
3. Tread the nipple (C) into loop (F) until snug.
4. Tread other end of nipple (C) with loop attached into crossbar (D) until snug.
5. Place lock washer (B) over end of nipple protruding through crossbar and tread hex nut (A) onto nipple until tight.
6. Take this crossbar assembly and mount to ceiling junction box with junction box screw (E). Tighten screws securely with screwdriver. This side of crossbar marked with "GND" must face out.
7. Use a pair of pliers to open one end of the fixture loop (J). Close the link.
8. By measuring, determine correct number of links needed for proper hanging height. Using pliers, disconnect and discard remaining chain.
9. Lace the fixture wires through the chain.
10. Slip loop collar (H) over the chain, then do the same with canopy (G).
11. Open the other end link of the chain and connect to the ceiling loop (F). Close the link.
12. Feed the fixture wires through the loop (F) and nipple (C) and pull until taut.

CONNECTING THE WIRE (See fig.2)

1. Take the black wire from the ceiling junction box and the smooth wire leg from the fixture and twist bare ends together. Twist wire connector onto end of wire until snug.
2. Repeat same process with white junction box wire and ribbed wire leg of fixture wire. NOTE: Twist wire together in the same direction you wire the connector onto wire.
3. If your junction box has a grounding wire (Green or bare copper), Attach this wire and the bare copper wire from the fixture together as step 1. If junction box has no ground wire. Attach the bare copper fixture wire to the green ground screw on the cross bar.
4. Tuck these wires connectors neatly into the ceiling outlet box and raise the loop (H) and tread onto ceiling loop protruding through canopy.

Your installation is now complete. Return power to the junction box and test the fixture.

